

MagConnect™ Universal Phone Module

JOY
thejoyfactory

Installation

Most surfaces are best prepared by cleaning with the included alcohol pad prior to applying the MagConnect Universal Phone Module. Exceptions to this general procedure may require additional surface preparation. A degreaser or solvent-based cleaner may be required to remove heavy oil or grease from a surface and should be followed by cleaning with rubbing alcohol 70-75% and completely dry with a soft micro fiber cloth. Some cases might have porous surface materials such as cloth or leather. Such surfaces might not work well with the MagConnect Universal Phone Module.

