



LAPTOP SECURITY CABLE


PARTS



Key



Pendant




Security Cable


SECURING TO A FIXING POINT

1a. Using the Key, rotate anti-clockwise to release the Pendant.


b. Lift and open the Pendant.




2. Take the Loop end of the cable and wrap it around a secured fixing point.



3. Attach the Pendant to the cable and close the Pendant.




4. Using the Key, rotate clockwise to secure the Pendant.




SECURING TO YOUR LAPTOP


5. Remove the rubber cap from the Lock end of the cable.




6. Insert the Lock into the 3.5 audio socket of your laptop.



7. Using the Key, rotate clockwise slowly until the Lock is secured in the audio socket.




8. Ensure the Lock is fully secured, then reattach the rubber cap.



REMOVING THE SECURITY CABLE

9a. Remove the rubber cap, then using the Key, rotate anti-clockwise to release the Lock.

b. Detach the Lock from your laptop and reattach the rubber cap for safe keeping.



10. Using the Key, rotate anti-clockwise to release the Pendant and unwrap it from the fixing point.

