

Smartphone Charging Cart


Handling Instructions

Ver.1.0



SLC30C

Product body / part name



Specification

| | |
|--------------------------------|---|
| Cart dimensions (W x H x D) | 500*770*75mm |
| Weight | 30kgs |
| Input Voltage | AC220-240V 50Hz 15A |
| Output Voltage | DC5-20V 20W Max |
| Storage/charging capacity | 30bays 6.7inch Smartphone |
| LED indicator | 30 LED lights indicator Red: charging Green: full Off: not working |
| Working environment | Temperature: -10~40°C Humidity: 20~80% |

Components

| | |
|------------|--------|
| Cart | 1 |
| Manual | 1 |
| Power Cord | 1 (2m) |
| Key | 4 |

Handling Precautions (Be sure to read)

warning

- Do not disassemble, repair, process or modify this product.
- Do not apply strong vibration, shock, or excessive force to this product.
- Do not use or store this product in a place exposed to water or underwater.
- Do not touch this product with wet hands.
- This product is powered by electricity and may catch fire. If smoke or a strange odor comes out, turn off the power of this product and the connected tablet device, and contact the store where you purchased the product or us.
- Do not use this product above 2,000m from sea level.

Note

- Our company shall not be liable for any direct or indirect damage caused by the failure of this product or its use.
Please note.
- We do not guarantee any damage, loss, or other troubles of data or programs that occur while using this product.
- Please use this product indoors only
- Do not store or store this product in an unstable place.
- When cleaning this product, do not use anything that contains volatile organic solvents such as benzene and thinner.
- Be sure to turn off the power of this product when connecting to an outlet with a power cord.
- Do not connect using an extension cord or power strip. Please plug it directly into a wall outlet.
- Please close the door of this product during use.
- Do not place heavy objects such as TVs and displays on this product.
- Do not use a damaged cable.
- When connecting or disconnecting the cable of this product or other equipment, be sure to hold the connector and do not apply excessive force.
- Be sure to turn off the power of this product when inserting or removing the tablet.
- Make sure that the tablet is turned off before connecting to this product.
- When moving this product, be sure to disconnect the power cord from the outlet.
- Move this product slowly.
- Lock the caster stopper when not moving.
- Do not charge or connect devices other than tablets.
- Do not unplug this product from the wall outlet when the operator's hands are wet.
- This product is not intended to be operated by children. Only adults should operate this product.
- Do not allow this product to get wet.
- Do not block the vents so as not to interfere with air circulation.
- Do not block the vent when charging.

Caution

- The rack may tip over cause serious personal injury Before extending the rack to the installation position, please read the installation instructions.
- Do not place any stress on the slide-rail mounted equipment of the installation position.
- Do not leave the slide-rail mounted equipment in the installation position.