





Specification iPad case 10,2"

Supported models	<ul style="list-style-type: none">- iPad 7th generation - 2019- iPad 8th generation - 2020
Weight	<ul style="list-style-type: none">- 377 g- 867 g (including iPad and lightning cable)
Dimensions	<ul style="list-style-type: none">- 293 x 197 x 36 mm- 15 mm (depth of face plate)- 16 x 16 x 16 x 36 (width of face plate)
Material	PC-ABS (Antibacterial)
Supported network(s)	<ul style="list-style-type: none">- Wi-Fi- Ethernet (requires additional components)- PoE (requires additional components)
VESA standard	VESA 75
VESA screws	M4 (not included)
Theft protection	Yes, using anti-theft screws
Audio options	<ul style="list-style-type: none">- Internal speakers- External using headphone jack plug- Bluetooth
Microphone options	<ul style="list-style-type: none">- Internal microphone- External using headphone jack- Bluetooth
Packaging Weight	490 g
Packaging dimensions	324 x 234 x 54 mm



Cleaning instructions

(Based on the Dutch guideline 'Bedden en toebehoren' (Werkgroep Infectie Preventie, 2014).)

Construction

- The case is constructed out of ABS plastic with an antibacterial coating. It is resistant to alcohol and detergents.
- The tablet is resistant to detergents and alcohol.
- The whole casing is NOT resistant to chlorine.
- The case and tablet are not resistant to submersion in water.

Frequency of cleaning

- After dismissal of a patient or in case of visual pollution, the whole case is to be cleaned.
- If a system is used for a long period by the same patient, the system is to be cleaned at least once every four weeks.
- A system on a short-stay wing (≤ 48 hours) will be cleaned at least once every week.

Method of cleaning

- After cleaning the system should be free of dust and visibly clean.
- Cleaning does not need to take place in a special room.
- Remove any bloodstains and/or other bodily fluids and disinfect the cleaned area with alcohol 70%.
- Use a damp microfiber cloth.
 - o Prevent the housing and tablet from getting excessively wet to prevent damage to electronics.
 - o Per bed (including accompanying furniture) a clean microfiber cloth must be used.

References

- National institute for public health and the environment, Ministry of health, welfare and sport. (<https://www.rivm.nl/dsresource?objectid=da8cc662-870a-4a14-a4b8-825a597a3a5a>)